


heatmiser®



heatmiser™

UH2



Manufactured in UK by: Heatmiser UK Ltd
Technical Support: 01254 776 343
www.heatmiser.co.uk




WARNING - 230v - 50Hz
DISCONNECT FROM ELECTRICAL SUPPLY
BEFORE REMOVING THIS COVER

Model: UH2



Wiring Diagram - UH2



This equipment should be installed by an appropriately qualified / registered electrician.
 Ensure all wiring is correct before applying power.
 The warranty does not cover any damages caused by incorrect wiring and installation.



Heating Professionals:

Request a copy of our product installation guide containing detailed technical specifications for our complete product range:
www.heatmiser.com/guide

Want More Information?

Call our support team on: +44 (0)1254 669090

Or view technical specifications directly on our website:
www.heatmiser.com



PDF



FAQ



Facebook:

facebook.com/thermostats



Twitter: [heatmiseruk](https://twitter.com/heatmiseruk)

Products Commonly Used With UH2 Wiring Centre:



PRT



PRTHW



DS1

Other Heatmiser Wiring Centres:



UH1



UH1-W



UH3